

Installation Instructions

Highway Bar for Steel Frame bikes

Thank you very much for your purchase. We hope our product will bring you years of enjoyment! Now, let's put it onto your bike. The assembly should be easy with simple household tools.

** This instruction applies to Luxor Highway Bar and Outlaw Highway Bar. These type of highway bars won't fit 2003-2007 models.



Included hardware



Tools you may need



1. It will be much easier to have a extra pair of hands to help.
2. Cover and protect your bike front fender with a nice soft, thick towel.
3. Bolt the included two (2) M10 screws through the highway bar upper mounting bracket and the two (2) spacers to the 2 holes where the horn is mounted. These 2 bolt locations are just underneath the horn.
4. Bolt the included two (2) M10 screws through the highway bar and the lower frame rails, secure these screws with the nuts.
5. You are ready to show off. Enjoy!